KIT: A36-62

6" Wide Aluminum Truss. 1" Chords with 5/16" Webs

©2015 EXHIBIT AND DISPLAY TRUSS.COM

Banner Wall



Toll Free: 855-323-4866
Email: info@exhibitanddisplaytruss.com

ExhibitAndDisplayTruss.com

KIT: A36-62

6" Wide Aluminum Truss. 1" Chords with 5/16" Webs

©2015 EXHIBIT AND DISPLAY TRUSS.COM

Banner Wall



©2015 EXHIBIT AND DISPLAY TRUSS.COM

EXPLODED VIEW

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	EDT6-BP2	Ladder Base Plate	4
2	EDT6-L2	2'-0" Ladder Truss	3
3	EDT6-L3	3'-0" Ladder Truss	8
4	EDT6-L2W90O	2 Way 90° Junction Horizontal Offset	2
5	EDT6-L3W135V-18V	3 Way 135° Junction Vertical (18" Vertical)	2
6	EDT1-STB41.125	41.125" Single Tube Brace (Center)	1
7	EDT1-STB38.625	38.625" Single Tube Brace (Sides)	2

KIT: A36-62

Banner Wall

6" Wide Aluminum Truss. 1" Chords with 5/16" Webs

©2015 EXHIBIT AND DISPLAY TRUSS.COM



TOP VIEW
UNITS: FEET & INCHES

©2015 EXHIBIT AND DISPLAY TRUSS.COM

Toll Free: 855-323-4866
Email: info@exhibitanddisplaytruss.com

KIT: A36-62

6" Wide Aluminum Truss. 1" Chords with 5/16" Webs

©2015 EXHIBIT AND DISPLAY TRUSS.COM

Banner Wall



FRONT VIEW
UNITS: FEET & INCHES

©2015 EXHIBIT AND DISPLAY TRUSS.COM

Toll Free: 855-323-4866
Email: info@exhibitanddisplaytruss.com

ExhibitAndDisplayTruss.com

KIT: A36-62

6" Wide Aluminum Truss. 1" Chords with 5/16" Webs

©2015 EXHIBIT AND DISPLAY TRUSS.COM

Banner Wall



SIDE VIEW
UNITS: FEET & INCHES

©2015 EXHIBIT AND DISPLAY TRUSS.COM

Toll Free: 855-323-4866
Email: info@exhibitanddisplaytruss.com